

# Kenmore Elite 665.15972, 15974, 15979, 15973 User Manual

[DOWNLOAD HERE](#)

Kenmore Elite 665.15972, 15974, 15979, 15973 user manual Dishwasher WE SERVICE WHAT WE SELL .....	2	WARRANTY .....	3
DISHWASHER SAFETY .....	4	Before Using Your Dishwasher .....	4
.....	5	PARTS AND FEATURES .....	6
ULTRA WASH* Soil Removal System .....	7	START-UP GUIDE .....	7
.....	8	Using Your New Dishwasher .....	8
LOADING YOUR DISHWASHER .....	8	Loading Suggestions .....	8
.....	8	Loading the Top Rack .....	9
Loading the Bottom Rack .....	10	Utensil Caddy .....	10
.....	11	Loading the Silverware Basket .....	11
USING YOUR DISHWASHER .....	12	Detergent Dispenser .....	12
.....	12	Rinse Aid Dispenser .....	13
Dishwasher Efficiency Tips .....	14	Control Panel .....	14
.....	15	Cycle Selection Chart .....	15
Canceling a Cycle .....	16	Changing a Cycle or Setting .....	16
.....	16	Adding Items During a Cycle .....	16
Favorite Cycle .....	16	Option Selections .....	16
.....	17	Cycle Status Indicators .....	18
Active Vent .....	19	Drying System .....	19
.....	19	Overfill Protection Float .....	19
WASHING SPECIAL ITEMS .....	19	CARING FOR YOUR DISHWASHER .....	19
.....	20	Cleaning Your Dishwasher .....	20
.....	20	Drain Air Gap .....	20
.....	21	Storing Your Dishwasher .....	21
TROUBLESHOOTING .....	22	76 pages Tags: 1 .....	22

[DOWNLOAD HERE](#)

Similar manuals: