

Kenmore 385.15212400, 385.15218400 Sewing Machine Manual

[DOWNLOAD HERE](#)

kenmore 385.15212400, 385.15218400 sewing machine manual SECTION t. NA_JaES OF PARTS

Cabinets and Sewing Machine Tote Bag	2. Names of Parts
..... 2 Available Accessories and Attachments	4
SECTION !1.GETTING READY TO SEW Connecting Machine to Power Supply	6
Before Using Your Sewing Machine	6 For Your Safety
..... 6 Polarized Plug	
.....6..... Controlling Sewing Speed	
..... 6 Setting Spool Pins	8..
Presser Foot Lifter	8 Thread Cutter
.....8 Accessory Box	8
Extension Table	10 Detaching the table
..... 10 Attaching the table	t.0..
Changing Needle 10 To Remove and Attach the Foot Holder	1..0 To remove
.....1..0... To attach	
.....1..0..... Changing Presser Foot	
.....1..2. To remove	1..2.....
To attach	t.2..... Presser Foot Types
.....1..2..... Zigzag foot	
.....1..2..... Automatic buttonhole foot	
.....12 Zipper foot	l.2.....
Straight stitch foot	14 Satin stitch foot
.....1..4..... Selecting Needle and Fabric	
.....1..6 Bobbin Winding	2..0-24
Removing bobbin case	2..0. -24 Bobbin winding

.....2.0.-.2.2.... Inserting bobbin	
.....2.4..... Threading the Machine	
.....2.6.-.2.8 Threading the machine	2.6.
Needle threader (Model I5218 exclusive)	2.6.... Drawing up bobbin thread
.....2.8... Adjust the Needle Thread Tension for a Straight Stitch	
.....2.8..... Correct tension	
.....2.8..... Tension is too tight	
.....2.8..... Tension is too loose	
.....3.0.. Adjust bobbin tension	
.....3.0.. Adjust the Needle Thread Tension for a Zigzag Stitch	30
Correct tension	3.0..... Tension is too tight
.....3.0..... Tension is too loose	
.....3.0 Stitch Pattern Selector	3.2
Stitch Length Control	3.2.... Stitch Width Control ;,
.....3.2... Reverse Stitch Control	3.2
SECTION III, STRAIGHT STITCH SEWING Straight Stitch	
.....3.4 Starting to sew	
.....3.4.... Finishing sewing	
.....3.4... Use the Seam Guides	
.....34 Turn a Square Corner	3.4.
Variable Needle Position	36 Topstitching
.....36 Zipper Sewing	
.....36-38 Fabric preparation	36
To sew	3.6.... To Drop or Raise the Feed Dogs
.....40 Darning	4.0.....
SECTION IV. ZIGZAG STITCH SEWING Basic Zigzag	
.....4.2... Satin Stitching	
.....42 Monogramming	
44 Applique	4.4. BarTacking

.....4.6.....	Button Sewing	
.....4.6.....	Overcasting Stitch	
.....4.8...	SECTION V. UTILITY AND DECORATIVE STITCHES	
Blind Hem Stitch	50	Lace Work
.....5.0.....	Shell Stitch	
.....5.2.....	Multiple Zigzag Stitch	
.....52	Seam finishing	5.2.....
Mending	5.2.....	Box Stitch (Model 15218 exclusive)
.....5.4	Decorative Stitch Patterns (Model 15218 exclusive)	54
(Option)	5.6. SECTION VI. STRETCH STITCHES	Straight Stretch
.....5.8....	Rick-rack Stretct_	
.....5.8.....	Overcast Stretch Stitching	
.....6.0.....	Starting to sew	6.0....
Smocking	60	To sew
.....60	Serging	
.....6.2.....	Elastic Stretch Stitch (Model 15218	
exclusive)	6.2. Decorative Stretch Patterns (Model 15218 exclusive) .	64
BUTTONHOLE Buttonhole	6.6.-.7.0.....	Preparation for
sewing	6.6..	To sew
.....6.6.-.	68	To adjust buttonhole stitch density
.....7.0...	Corded Buttonhole	7.0.....
VIII. CARE OF YOUR MACHINE	Replacing the Light Bulb	7.2
Cleaning	the Feed Dogs	7.2..
Cleaning the Shuttle Race	7.4....	Cleaning the shuttle area
.....7.4..		
Replacing shuttle assembly	7.4	Oiling the Machine
.....7.6	Oil behind the face cover	
.....7.6.....	Oil the shuttle area	7.6.....
Troubleshooting	78	93 pages

[DOWNLOAD HERE](#)

Similar manuals: