

Singer Kenmore 384.13012000 Sewing Machine Manual

[DOWNLOAD HERE](#)

Singer Kenmore 384.13012000 sewing machine manual IMPORTANT SAFETY INSTRUCTIONS

| | |
|--|--------------------------------|
| 5 WARRANTY | 8 - 9 GETTING TO KNOW YOUR |
| MACHINE Cabinet and Tote bags | 10 Names of Parts |
| 10 Available Accessories and Attachments | 12 |
| GETTING READYTO SEW Connecting Machine to Power Supply | 14 For Your Safety |
| 14 When Finished Sewing | 14 |
| Operating Instructions | 14 Controlling Sewing Speed |
| 14 Setting Spool Pins | 16 Presser Foot |
| Lifter | 16 Thread Cutter |
| 16 | |
| Accessory Box | 16 Free-arm Sewing |
| 18 For free-arm sewing | 18 For |
| flat-bed sewing | 18 Changing Needle |
| 18 Changing Presser Foot | 18 Presser |
| Foot Types | 20 Zigzag foot |
| 20 | |
| Sliding buttonhole foot | 20 Zipper foot |
| 20 Hemmer foot | 20 |
| Replacement Bobbins | 22 Bobbin Winding |
| 22 - 26 Removing bobbin case | 22 Bobbin |
| winding | 22 - 24 Inserting bobbin |
| 26 | |
| Threading the Machine | 28 Threading the machine |
| 28 Drawing up bobbin thread | 28 Adjust the |
| Needle Thread Tension for Straight Stitch ... | 30 Correct tension |
| 30 | |
| Tension is too tight | 30 Tension is too loose |
| 30 Adjust the Needle Thread Tension for Zigzag Stitch | 32 Correct |
| tension | 32 Tension is too tight |
| 32 | |

| | |
|---|--|
| Tension is too loose | 32 Stitch Selector |
| | 34 Stitch Length Control 34 |
| Adjusting Stretch Stitch Balance | 34 Reverse Stitch Control |
| | 34 STRAIGHT STITCHES Straight Stitch |
| | 36 Starting to sew 36 |
| Finishing sewing | 36 Use the Seam Guides |
| | 36 Turn a Square Corner 36 Topstitching |
| | 38 Zipper Sewing 38 - 40 |
| Fabric preparation | 38 Starting to sew |
| | 40 To Drop or Raise the Feed Dogs 42 Darning |
| | 42 Rolled Hem 44 |
| BUILT-IN STITCHES Basic Zigzag | 46 Overcasting Stitch |
| | 46 Blind Hem Stitch 48 Straight |
| Stretch | 48 Rick-rack Stretch 50 |
| Overcast Stretch Stitching | 50 Starting to sew |
| 50 Serging | 52 DECORATIVE STITCHES Lace Work |
| | 52 Multiple Zigzag Stitch 54 Shell |
| Stitch | 54 Smocking 56 |
| BUTTONHOLE STITCHES Buttonhole | 58 - 61 Starting to sew |
| | 58 ADDITIONAL STITCHES Satin Stitch |
| | 62 Monogramming 62 |
| Applique | 64 Bar Tacking |
| | 64 Button Sewing 66 CARE |
| OFYOUR MACHINE Replacing the Light Bulb | 68 Cleaning the Feed Dogs |
| | 68 Cleaning the Shuttle Race 70 Cleaning the shuttle |
| area | 70 Replacing shuttle assembly 70 Oiling the Machine |
| | 72 Oil behind the face cover 72 Oil the shuttle |
| area | 72 Troubleshooting 74 Fabric, |
| Thread and Needle Table | 77 80 pages |

[DOWNLOAD HERE](#)

Similar manuals: